Bluetooth Protocol for the ADT685

1. Connection procedures

1.1 Search for devices

Search for peripheral Bluetooth devices through service UUID and broadcast packets, and initiate a connection after finding them.

The Bluetooth connection interfaces of mobile phones and computers may not be able to display these gauges because they will block Bluetooth devices that are useless to them, so please use professional Bluetooth software to search.

1.2 Get notification and write characteristic value

After the connection is successful, get the notification and write characteristic value based on the service UUID and characteristic value UUID, and open the notification immediately.

1.3 Send handshake command to gauge

For the ADT685 and ADT685Ex, the gauge will send command "CODE?" to Bluetooth client, then the client should send handshake command "@" to the gauge, with terminator "\r\n". If the Bluetooth client fails to send handshake command within 5 seconds, the communication will be disconnected.

1.4 Communication

After the handshake connection established, use notification and write characteristics to receive and send SCPI commands from the device.

2. Protocol

Please refer to the programming command documents of the units.

Appendix 1: Broadcast packet data format

(1) FLAG

(1) 1 EAG						
Length	Туре	Content				
1 Byte	0x01	0X06				
(2) Device name						
Length	Туре	Content				

•	1 Byte		0x09		0~13 Bytes	
(3) Manufacturer-defined data						
Length	Туре	VID	PID	MID	MAC	
1 Byte	0xFF	2 Bytes	2 Bytes	1 Byte	6 Bytes	

Appendix 2: UUID definition

Device	Communication Service	Notification	Write Characteristic	
	UUID	Characteristic UUID	UUID	
1)P(i	AF661820-D14A-4B21-	1B6B9415-FF0D-47C2-	1B6B9415-FF0D-47C2-	
	90F8-54D58F8614F0	9444-A5032F727B2D	9444-A5032F727B2D	